

# SEATERHEADS - TRIEBEL Seaterhead - Caliber 8,5/.338 - Type: R37

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

**You will find further informations in the manual.**

[The manual can be found here](#)

NO IMAGE  
AVAILABLE

## Attributes

- Name: [TRIEBEL Seaterhead - Caliber 8,5/.338 - Type: R37](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008361
- Mfr. No.: 3000171
- Diameter (in): 0.338
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

# Table of Contents

- [Startpage](#)
- [TRIEBEL Seaterhead Safety Instruction Guide](#)
- [About Us](#)

# TRIEBEL Seaterhead Safety Instruction Guide

## Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 8.5/.338 Type: R37. This accessory is designed for use with crimp and benchrest seaters from Triebel. To ensure safe and effective use, please carefully read and follow the safety instructions outlined in this guide.

## General Safety Guidelines

- Ensure that you read and understand all instructions before using the product.
- Only use the TRIEBEL Seaterhead with compatible equipment as specified by the manufacturer.
- Always keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear. Do not use if damaged.
- In case of any malfunction or abnormal operation, discontinue use immediately and seek assistance.

## Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, while using the Seaterhead.
- Ensure that your workspace is clean, dry, and well-lit to prevent accidents.
- Avoid distractions while using the product to maintain focus on the task at hand.
- Do not exceed the manufacturer's recommended specifications for use, including caliber and pressure.
- Be aware of your surroundings and ensure that no unauthorized persons are nearby during operation.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that the equipment is turned off and unplugged before installation.
- Carefully follow the manufacturer's instructions to securely attach the Seaterhead to your crimp or benchrest seater.
- Verify that all connections are tight and that there are no loose parts.

### 2. Usage:

- Check that the Seaterhead is properly installed and functioning before each use.
- Set up your workspace according to the guidelines provided, ensuring all necessary tools are within reach.
- Load the appropriate caliber (.338) as specified for the Seaterhead.
- Follow the operational guidelines provided with your seater to ensure proper usage of the Seaterhead.
- After use, clean the Seaterhead and surrounding area to prevent residue buildup.

## Disposal Instructions

- Dispose of the TRIEBEL Seaterhead in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the product is no longer usable, consider recycling components where applicable.

## Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the EU-based contact point provided with your

product documentation.

## **Conclusion**

By following these safety instructions, you can ensure a safe and efficient experience with your TRIEBEL Seaterhead. Always prioritize safety and stay informed about best practices for using your equipment. Thank you for your attention to these guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)