

SEATERHEADS - TRIEBEL Seaterhead - Caliber 8,5/.338 - Type: R50

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 8,5/.338 - Type: R50](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008362
- Mfr. No.: 3000176
- Diameter (in): 0.338
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- TRIEBEL Seaterhead Caliber 8,5/.338 Safety Instruction Guide
- About Us

TRIEBEL Seaterhead Caliber 8,5/.338 Safety Instruction Guide

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 8,5/.338. This product is designed to enhance your reloading experience with precision and safety. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always handle the TRIEBEL Seaterhead with care and follow all safety instructions to prevent accidents.
- Ensure that you are using the product in a suitable environment, free from distractions and hazards.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seaterhead for any signs of damage or wear before each use.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Use only compatible components as specified in the product manual.
- Wear appropriate safety gear, including eye protection and hearing protection, when using the Seaterhead.
- Ensure that the work area is wellventilated to avoid inhalation of dust or fumes.
- Do not exceed the manufacturer's specified limits for pressure and load when using the Seaterhead.
- Never leave the Seaterhead unattended while in use.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is securely mounted and stable.
- Carefully attach the TRIEBEL Seaterhead to the reloading press according to the manufacturer's instructions.
- Check that the connection is secure before proceeding.

2. Usage

- Before starting, read the manual thoroughly to understand the operation of the Seaterhead.
- Set the desired seating depth according to your load specifications.
- Place a cartridge case into the Seaterhead and ensure it is properly aligned.
- Pull the handle of the reloading press smoothly and steadily to seat the bullet.
- Inspect the seated bullet to ensure it is correctly positioned and seated to the desired depth.
- Repeat the process for each cartridge, maintaining focus and control throughout.

Disposal Instructions

- Dispose of any damaged or worn components of the TRIEBEL Seaterhead in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for recycling programs or hazardous waste disposal options in your area.

Contact Information for Further Support

For any inquiries or further assistance regarding the TRIEBEL Seaterhead, please refer to the product manual or contact your local retailer.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your TRIEBEL Seaterhead Caliber 8,5/.338. Always prioritize safety and stay informed about best practices in reloading. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk