

SEATERHEADS - TRIEBEL Seaterhead - Caliber 8/.323 - Type: KJG, MJG

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 8/.323 - Type: KJG, MJG](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008372
- Mfr. No.: 3000154
- Diameter (in): 0.323
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- TRIEBEL Seaterheads Safety Instruction Guide
- About Us

TRIEBEL Seaterheads Safety Instruction Guide

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 8/323 Type: KJG, MJG. This product is designed to enhance your reloading experience. To ensure safe and effective use, please read this safety instruction guide carefully and follow all guidelines.

General Safety Guidelines

- Always handle the Seaterhead with care to prevent injury.
- Ensure that the product is used in accordance with the manufacturer's specifications.
- Store the Seaterhead in a cool, dry place, away from direct sunlight and moisture.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the Seaterhead for any signs of damage or wear before use.
- Report any unsafe conditions or accidents related to the product to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as safety glasses and gloves, when using the Seaterhead.
- Ensure that the Seaterhead is securely attached to the reloading press before use.
- Avoid overtightening the Seaterhead, as this may cause damage or malfunction.
- Do not exceed the recommended load limits specified in the manual.
- Be aware of potential hazards, such as sharp edges or small parts, when handling the product.
- If you are inexperienced with reloading equipment, seek guidance from a knowledgeable person.

Instructions for Installation and Usage

1. Installation

- Ensure that the reloading press is turned off and unplugged before installation.
- Remove any previous Seaterheads or attachments from the reloading press.
- Carefully attach the TRIEBEL Seaterhead to the press, ensuring it is aligned properly.
- Tighten the attachment securely, but do not overtighten.
- Doublecheck that the Seaterhead is firmly in place before proceeding.

2. Usage

- Prepare your reloading materials according to the specifications in the manual.
- Set the desired depth of the bullet seating based on your reloading needs.
- Load the bullet into the Seaterhead and activate the reloading press to seat the bullet.
- Monitor the process to ensure that each bullet is seated correctly.
- After use, clean the Seaterhead to remove any debris or residue.

Disposal Instructions

- Dispose of the TRIEBEL Seaterhead and any associated packaging materials in accordance with local regulations.
- Do not dispose of the product in household waste. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the contact information provided in the product manual.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk