

# SEATERHEADS - TRIEBEL Seaterhead - Caliber 9,3/.366 - Type: R39

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

**You will find further informations in the manual.**

[The manual can be found here](#)

NO IMAGE  
AVAILABLE

## Attributes

- Name: [TRIEBEL Seaterhead - Caliber 9,3/.366 - Type: R39](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008386
- Mfr. No.: 3000190
- Diameter (in): 0.366
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

# Table of Contents

- Startpage
- TRIEBEL Seaterheads Safety Instruction Guide
- About Us

# TRIEBEL Seaterheads Safety Instruction Guide

## Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 9,3/.366 Type: R39. This product is designed to enhance your reloading experience with safety and efficiency in mind. Please read this safety instruction guide carefully to ensure safe use and compliance with EU safety regulations.

## General Safety Guidelines

- Ensure that you are familiar with the product and its intended use before operating.
- Always keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage.
- Use the product only for its intended purpose as described in this manual.
- In case of any doubts or questions regarding safety, consult the manual or reach out for support.

## Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when using the Seaterhead.
- Do not exceed the recommended specifications for your reloading equipment.
- Avoid using the product in wet or damp conditions to prevent electrical hazards.
- Ensure that the work area is clean and free from obstructions before use.
- Be aware of your surroundings and ensure that no one is in close proximity while operating the product.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that your reloading press is compatible with the TRIEBEL Seaterhead.
- Securely attach the Seaterhead to the reloading press according to the manufacturer's instructions.
- Check that all components are tightly fastened and that there are no loose parts.

### 2. Usage:

- Before starting, verify that all tools and materials are in good condition and appropriate for use with the Seaterhead.
- Load the appropriate caliber and ensure that the Seaterhead is properly adjusted for the desired crimping specifications.
- Follow the reloading procedures as outlined in the manual, taking care to avoid any actions that could lead to accidents or malfunctions.
- After use, clean the Seaterhead and store it in a safe, dry location.

## Disposal Instructions

- Dispose of the product in accordance with local regulations for hazardous materials.
- Do not discard in regular household waste.
- Contact your local waste disposal authority for guidance on proper disposal methods.

## Contact Information for Further Support

For any questions or concerns regarding the TRIEBEL Seaterhead, please refer to the manual or contact your local distributor for assistance.

Thank you for your attention to these safety guidelines. Enjoy your reloading experience with the TRIEBEL Seaterhead!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)