

SEATERHEADS - TRIEBEL Seaterhead - Caliber 9,5/.375 - Type: R62

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 9,5/.375 - Type: R62](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2008401
- Mfr. No.: 3000192
- Diameter (in): 0.375
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- TRIEBEL Seaterhead Safety Instructions
- About Us

TRIEBEL Seaterhead Safety Instructions

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 9.5/.375 Type R62. This product is designed to enhance your reloading experience. Please read this safety instruction guide carefully to ensure safe and effective use.

General Safety Guidelines

- Always follow the manufacturer's instructions when using the TRIEBEL Seaterhead.
- Ensure that the Seaterhead is compatible with your reloading equipment.
- Inspect the product for any signs of damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use the Seaterhead only for its intended purpose as described in the manual.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, while handling reloading equipment.
- Do not exceed the recommended load limits for your Seaterhead.
- Ensure that your workspace is clean and free from distractions while using the Seaterhead.
- Always doublecheck that the Seaterhead is securely attached to your reloading press before use.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged.
- Select the appropriate Seaterhead for your caliber.
- Align the Seaterhead with the press and secure it according to the manufacturer's instructions.
- Check for a tight fit to prevent any movement during operation.

2. Usage:

- Prepare your brass cases and ensure they are clean and free of debris.
- Set the desired seating depth according to your load specifications.
- Place a bullet in the case mouth and position it under the Seaterhead.
- Activate the reloading press to seat the bullet into the case.
- Inspect the completed rounds for proper seating and any irregularities.

Disposal Instructions

- Dispose of the TRIEBEL Seaterhead responsibly when it is no longer needed.
- Follow local regulations for the disposal of metal and plastic products.
- Avoid discarding the product in regular household waste.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product information, please refer to the manual or contact the manufacturer directly.

By following these safety instructions, you can ensure a safe and efficient reloading experience with the

TRIEBEL Seaterhead. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk