

SEATERHEADS - TRIEBEL Seaterhead - Caliber 8/.323 - Type: R

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 8/.323 - Type: R](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2009041
- Mfr. No.: 3000155
- Diameter (in): 0.323
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- Safety Instruction Guide for TRIEBEL Seaterhead Caliber 8/.323 Type: R
- About Us

Safety Instruction Guide for TRIEBEL Seaterhead Caliber 8/.323 Type: R

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 8/.323 Type: R. This product is designed to enhance your reloading experience with safety and efficiency. It is important to read and understand this safety instruction guide to ensure safe use and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always handle the Seaterhead with care to avoid injury.
- Ensure that you are familiar with the reloading equipment and processes before using this product.
- Keep this product out of reach of children and vulnerable individuals.
- Regularly inspect the Seaterhead for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Use only with compatible Seater and BenchRestSeaters from Triebel.
- Do not exceed the recommended specifications for the Seaterhead.
- Avoid using the Seaterhead in wet or damp conditions to prevent electrical hazards.
- Always wear appropriate safety gear, including eye protection, when operating reloading equipment.
- If you notice any irregularities during use, stop immediately and inspect the equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Carefully attach the TRIEBEL Seaterhead to your reloading press according to the manufacturer's instructions.
- Make sure the Seaterhead is securely fastened and properly aligned.

2. Usage:

- Before starting, check that the Seaterhead is clean and free of obstructions.
- Set the desired settings on your reloading press according to the specifications for the caliber you are using.
- Load the appropriate cartridge case into the Seaterhead.
- Follow the reloading process as outlined in your reloading manual, ensuring that you apply consistent pressure during the seating process.
- After use, clean the Seaterhead to maintain its performance and longevity.

Disposal Instructions

- Dispose of the TRIEBEL Seaterhead in accordance with local waste disposal regulations.
- Do not dispose of the product in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the TRIEBEL Seaterhead, please refer to the manufacturer's contact details provided in the product manual. It is important to have access to support for any safety inquiries or product issues.

By adhering to the guidelines and instructions provided in this safety instruction guide, you can ensure a safe and effective reloading experience with the TRIEBEL Seaterhead Caliber 8/.323 Type: R. Always prioritize safety and compliance with relevant regulations.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk