

SEATERHEADS - TRIEBEL Seaterhead - Caliber 10,3/.415 - Type: MJG

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 10,3/.415 - Type: MJG](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2009051
- Mfr. No.: 3000209
- Diameter (in): 0.415
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- [Startpage](#)
- [TRIEBEL Seaterhead Safety Instruction Guide](#)
- [About Us](#)

TRIEBEL Seaterhead Safety Instruction Guide

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 10,3/.415 Type: MJG. This product is designed to enhance your reloading experience with safety and precision. It is essential to read and understand this safety instruction guide before using the product to ensure safe operation and compliance with EU safety regulations.

General Safety Guidelines

- Always use the TRIEBEL Seaterhead in accordance with the manufacturer's instructions.
- Ensure that the product is suitable for your specific reloading equipment and caliber.
- Regularly inspect the Seaterhead for any signs of wear or damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use personal protective equipment such as safety glasses and gloves while operating the Seaterhead.
- Avoid wearing loose clothing or jewelry that may get caught in the equipment.
- Ensure that your work area is clean, dry, and welllit to prevent accidents.
- Do not exceed the recommended specifications for the Seaterhead.
- Be cautious when handling reloading components and tools; they can pose risks if not managed properly.
- Store the Seaterhead in a secure location when not in use to prevent unauthorized access.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and disconnected from any power source before installation.
- Carefully remove the Seaterhead from its packaging.
- Attach the Seaterhead to your reloading press according to the manufacturer's instructions.
- Ensure that the Seaterhead is securely fastened and properly aligned.

2. Usage:

- Follow the reloading process as outlined in your reloading manual.
- Use the Seaterhead only with compatible components, specifically designed for the 10,3/.415 caliber.
- Monitor the operation closely to ensure that everything is functioning correctly.
- If you notice any unusual sounds or resistance during operation, stop immediately and inspect the equipment.

Disposal Instructions

- Dispose of the TRIEBEL Seaterhead in accordance with local regulations concerning electronic and mechanical waste.
- Do not discard the product in regular household waste.
- If the product is damaged or no longer usable, consider recycling it at a designated facility.

Contact Information for Further Support

For any questions or concerns regarding the TRIEBEL Seaterhead, please refer to the manufacturer's website or contact the appropriate customer support channels. Always ensure that you have the product's model number and details at hand for efficient assistance.

Thank you for prioritizing safety while using the TRIEBEL Seaterhead. Your careful attention to these guidelines will help ensure a safe and enjoyable reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk