

SEATERHEADS - TRIEBEL Seaterhead - Caliber 10,57/.416 - Type: RWS KS

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Accessory for Seater with Crimp and Bench-Rest-Seaters from Triebel.

You will find further informations in the manual.

[The manual can be found here](#)

NO IMAGE
AVAILABLE

Attributes

- Name: [TRIEBEL Seaterhead - Caliber 10,57/.416 - Type: RWS KS](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2009059
- Mfr. No.: 3000226
- Diameter (in): 0.416
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm

Table of Contents

- Startpage
- TRIEBEL Seaterheads Safety Instruction Guide
- About Us

TRIEBEL Seaterheads Safety Instruction Guide

Introduction

Thank you for choosing the TRIEBEL Seaterhead Caliber 10,57/.416 Type: RWS KS. This accessory is designed to enhance your reloading experience with precision and safety. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always handle the Seaterhead with care to prevent accidents.
- Ensure that the Seaterhead is compatible with your specific reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seaterhead for any signs of wear or damage.
- Follow all local laws and regulations regarding ammunition reloading and usage.
- In case of any unsafe product conditions or incidents, report them to the relevant authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves while handling reloading equipment.
- Avoid using the Seaterhead in wet or damp environments to prevent electrical hazards.
- Do not exceed the recommended specifications for the Seaterhead, including maximum pressure limits.
- Ensure that your workspace is wellventilated when using the Seaterhead.
- Never leave the Seaterhead unattended while in use.
- Be cautious of hot surfaces and components during and after use.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is turned off and unplugged before installation.
- Carefully remove the existing Seater or bushing from the reloading press.
- Align the TRIEBEL Seaterhead with the press and secure it according to the manufacturer's instructions.
- Verify that the Seaterhead is firmly attached and properly aligned before use.

2. Usage

- Check that all components are clean and free from debris before starting the reloading process.
- Follow the specific reloading procedures outlined in your reloading manual.
- Use the Seaterhead only for the intended caliber (10,57/.416) to ensure safety and accuracy.
- Monitor the reloading process closely and stop immediately if you notice any irregularities.

Disposal Instructions

- Dispose of any damaged or worn components in accordance with local regulations.
- Do not dispose of the Seaterhead in regular household waste. Instead, follow your local guidelines for hazardous waste disposal.
- Ensure that all packaging materials are recycled or disposed of responsibly.

Contact Information for Further Support

For any questions or concerns regarding the TRIEBEL Seaterhead, please refer to the product manual or contact your local distributor for assistance. Always ensure that you have the latest safety updates and product information.

By following these guidelines, you can ensure a safe and effective experience with your TRIEBEL Seaterhead. Thank you for prioritizing safety in your reloading practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk