

Shotgun Chamber Flag - Brownells

[Shooting Accessories](#) > [Training & Safety Gear](#) > [Chamber Safety Flags](#)

Bright Neon green chamber flags to easily identify an unloaded firearm.

NO IMAGE
AVAILABLE

Attributes

- Name: [Shotgun Chamber Flag - Brownells](#)
- Manufacturer: [Brownells Europe](#)
- Product no.: EU2012002
- Mfr. No.: EU2012002
- Colour: Neon Green
- Delivery weight: 0.1kg

Table of Contents

- Startpage
- Shotgun Chamber Flag Safety Instructions
- About Us

Shotgun Chamber Flag Safety Instructions

Introduction

Thank you for choosing the Shotgun Chamber Flag by Brownells. This product is designed to enhance firearm safety by clearly indicating that a shotgun is unloaded. Please read this safety instruction guide carefully to ensure safe and proper use of the chamber flag.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Use the chamber flag only when the firearm is unloaded.
- Ensure that the chamber flag is visible at all times when the firearm is not in use.
- Store the chamber flag in a safe place when not in use, away from children and unauthorized users.
- Regularly inspect the chamber flag for any damage or wear before use.

Specific Safety Precautions for Use

- **Identification of Hazards:**

- Improper use of the chamber flag may lead to misunderstandings about the firearm's status.
- The chamber flag is not a substitute for safe firearm handling practices.

- **Instructions for Avoiding Hazards:**

- Always visually and physically inspect the firearm to confirm it is unloaded before inserting the chamber flag.
- Do not use the chamber flag if it shows signs of damage.

- **Age Specific Warnings:**

- This product is not intended for use by children without adult supervision.
- Ensure that children are educated about firearm safety and the importance of using a chamber flag.

Instructions for Installation and Usage

1. **Installation:**

- Open the action of the shotgun to ensure it is unloaded.
- Visually and physically inspect the chamber and magazine to confirm there are no shells present.
- Insert the chamber flag into the chamber of the shotgun, ensuring it is fully seated.

2. **Usage:**

- The chamber flag should remain in place while the firearm is not in use.
- Remove the chamber flag only when you are ready to use the firearm and have confirmed it is unloaded.

3. **Post Use:**

- After using the firearm, always reinsert the chamber flag to indicate that the firearm is unloaded.
- Store the firearm safely and securely.

Disposal Instructions

- Dispose of the chamber flag responsibly.
- If the chamber flag is damaged or no longer needed, place it in regular waste.
- Do not attempt to recycle or repurpose the chamber flag.

Contact Information for Further Support

For any questions or concerns regarding the Shotgun Chamber Flag, please refer to the contact information provided on the packaging or visit the manufacturer's website.

By following these safety instructions, you can help ensure that your use of the Shotgun Chamber Flag promotes a safer environment for yourself and others. Please stay informed about product safety updates and recalls via the EU's Safety Gate platform.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk