

Rifle Chamber Flag - Brownells Patch

[Shooting Accessories](#) > [Training & Safety Gear](#) > [Chamber Safety Flags](#)

Bright Neon green chamber flags to easily identify an unloaded firearm.

NO IMAGE
AVAILABLE

Attributes

- Name: [Rifle Chamber Flag - Brownells Patch](#)
- Manufacturer: [Brownells Europe](#)
- Product no.: EU2012014
- Mfr. No.: EU2012014
- Colour: Neon Green
- Delivery weight: 0.1kg

Table of Contents

- [Startpage](#)
- [Rifle Chamber Flag Safety Instruction Guide](#)
- [About Us](#)

Rifle Chamber Flag Safety Instruction Guide

Introduction

Thank you for choosing the Rifle Chamber Flag manufactured by Brownells. This product is designed to enhance firearm safety by clearly indicating that a firearm is unloaded. Please read this safety instruction guide carefully to ensure the safe use of the Rifle Chamber Flag.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Use the Rifle Chamber Flag to visibly indicate that a firearm is unloaded.
- Ensure that the chamber flag is correctly inserted into the firearm's chamber before handling.
- Keep the Rifle Chamber Flag out of reach of children and unauthorized users.
- Regularly inspect the Rifle Chamber Flag for wear and tear; do not use if damaged.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure the firearm is pointed in a safe direction when inserting or removing the chamber flag.
- Only use the Rifle Chamber Flag in firearms that are compatible with its design.
- Do not rely solely on the chamber flag; always verify the status of the firearm manually.
- Avoid using the chamber flag in environments where it may be mistaken for a loaded firearm.

Instructions for Installation and Usage

1. Inserting the Chamber Flag:

- Open the action of the firearm.
- Insert the Rifle Chamber Flag into the chamber until it is fully seated.
- Close the action of the firearm to secure the chamber flag in place.

2. Removing the Chamber Flag:

- Open the action of the firearm.
- Carefully remove the Rifle Chamber Flag from the chamber.
- Ensure the firearm is unloaded before storing or transporting it.

3. Storage:

- Store the Rifle Chamber Flag in a cool, dry place away from direct sunlight.
- Keep the chamber flag in its original packaging or a designated storage container when not in use.

Disposal Instructions

- Dispose of the Rifle Chamber Flag in accordance with local regulations.
- If damaged, do not attempt to repair. Dispose of it responsibly to prevent misuse.

Contact Information for Further Support

For any questions or concerns regarding the Rifle Chamber Flag, please refer to the contact information provided by the retailer or manufacturer where you purchased the product.

Conclusion

By following these safety instructions, you can help ensure the safe use of your Rifle Chamber Flag. Always prioritize safety when handling firearms and stay informed about best practices. Thank you for your commitment to firearm safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk