

Bow Post 1.5

[Shooting Accessories](#) > [Duty Gear](#)

The Bow Post replaces the arrow rest bolt on your bow, offering a versatile solution for attaching your bow to a Clamp Lock on your belt or backpack. This innovative accessory enhances your outdoor experience, making hiking and glassing more enjoyable and hassle-free.

1. Arrow Rest Bolt Replacement: The Bow Post seamlessly replaces the standard arrow rest bolt on your bow.
2. Universal Compatibility: Features 5/16-24 threads, ensuring compatibility with most bows.
3. Connects to Lock and Grip-On Families: Effortlessly integrates with the Lock family (e.g., Clamp Lock) and Grip-On family for maximum versatility.

NO IMAGE
AVAILABLE

Choosing the Right Bow Post:

4. Shorter is Better: Use the shortest Bow Post that fits your setup.
5. For Parallel Arrow Quivers: If your quiver runs parallel to your bow, ensure the Bow Post is long enough to extend beyond your arrow shafts. Usually, a 1.5" or 2" Bow Post is ideal.
6. For Perpendicular or Offset Quivers: If your quiver is perpendicular or offset from your arrow rest bolt, a 1" Bow Post is typically sufficient.

Recommended Accessories:

7. Clamp Lock with Tek-Lok: For belt attachment, the Tek-Lok version offers superior stability compared to the standard Clamp Lock.

Additional Use Case:

8. The Bow Post is also a handy tool for organization. Pair it with a Camera Lock to mount your bow on the wall, keeping your workspace tidy and your equipment easily accessible.

Elevate your bow setup with the Bow Post—functional, reliable, and designed for adventure.

Attributes

- Name: [Bow Post 1.5](#)
- Manufacturer: [OBI SYSTEMS](#)
- Product no.: EU2013655
- Mfr. No.: OBi01106-BLK
- Colour: Black
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 767637840972

Table of Contents

- Startpage
- Bow Post Safety Instruction Guide
- About Us

Bow Post Safety Instruction Guide

Introduction

Thank you for choosing the Bow Post 1.5. This innovative accessory is designed to enhance your outdoor experience by providing a reliable solution for attaching your bow to a Clamp Lock on your belt or backpack. To ensure safe and effective use, please read and follow this safety instruction guide.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the Bow Post by following all instructions and guidelines provided. This product is designed to meet safety standards applicable to nonfood products.
- **Enhanced Recalls:** Stay informed about any recalls or safety notices related to the Bow Post. If a recall occurs, follow the instructions provided for remedies.
- **Online Shopping:** If purchased online, ensure that the platform complies with safety requirements similar to those of physical stores.
- **Special Consumer Focus:** Extra care should be taken when using this product around vulnerable groups, including children.
- **EU Contact Point:** For any safety inquiries, please refer to the designated EU contact point provided with your product.
- **Rapid Alerts:** Keep an eye on the EU's Safety Gate platform for updates on any unsafe products.

Specific Safety Precautions for Use

- **Inspection Before Use:** Always inspect the Bow Post for any signs of damage or wear before each use. Do not use if damaged.
- **Proper Attachment:** Ensure the Bow Post is securely attached to your bow and that all connections are tight to prevent accidental detachment during use.
- **Weight Limits:** Be aware of the weight limits of your bow and accessories. Exceeding these limits can cause failure of the Bow Post.
- **Avoid Overextension:** Do not extend the Bow Post beyond its recommended length, as this may compromise stability and safety.
- **Use in Appropriate Conditions:** Avoid using the Bow Post in extreme weather conditions. High winds or heavy rain may affect stability and safety.
- **Keep Away from Children:** This product is not a toy. Keep it out of reach of children to prevent accidents.

Instructions for Installation and Usage

1. Installation:

- Remove the existing arrow rest bolt from your bow.
- Align the Bow Post with the mounting hole.
- Securely screw the Bow Post into place, ensuring it is tightly fastened to prevent movement.

2. Usage:

- Attach your bow to the Clamp Lock or GripOn family as needed.
- When using with parallel arrow quivers, ensure the Bow Post extends beyond your arrow shafts for optimal safety.
- For perpendicular or offset quivers, a 1" Bow Post is typically sufficient.

3. Recommended Accessories:

- For belt attachment, consider using the Clamp Lock with TekLok for enhanced stability.
- To organize your workspace, pair the Bow Post with a Camera Lock for wall mounting.

Disposal Instructions

- **Environmental Responsibility:** Dispose of the Bow Post in accordance with local regulations. Do not throw it in regular household waste.
- **Recycling:** If possible, recycle the product according to local recycling guidelines to reduce environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the Bow Post, please refer to the contact information provided with your product packaging or visit the manufacturer's website for additional support.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Bow Post. Thank you for your attention to these important guidelines. Enjoy your outdoor adventures!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk