

GripON Long Strap

[Shooting Accessories](#) > [Duty Gear](#)

The Long Strap is a 30cm strap.

The Grip On family is our most diverse product line. The Grip On comes standard with a U-Plate Arca, which mounts in any direction. The Grip On also comes with a 22,8cm strap and will fit most binoculars, tripod legs, smaller cups/water bottles, and anything else you can find to attach. Attach the Grip On by loosening the strap until it fits around the gear, pull the strap snugly, and then tighten the Allen bolt to the desired tension.

NO IMAGE
AVAILABLE

Attributes

- Name: [GripON Long Strap](#)
- Manufacturer: [OBI SYSTEMS](#)
- Product no.: EU2013665
- Mfr. No.: OBi01203-BLK
- Colour: Black
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 767637840866

Table of Contents

- Startpage
- GripON Long Strap Safety Instructions
- About Us

GripON Long Strap Safety Instructions

Introduction

Thank you for choosing the GripON Long Strap. This product is designed for versatility and convenience, suitable for various gear attachments such as binoculars, tripod legs, and water bottles. To ensure your safety and the proper use of the GripON Long Strap, please read this guide carefully.

General Safety Guidelines

- Ensure the GripON Long Strap is used in accordance with the manufacturer's guidelines to avoid potential hazards.
- Always inspect the strap for any signs of wear or damage before use. Do not use if damaged.
- Keep the strap out of reach of children and vulnerable individuals to prevent accidents.
- Use the strap only for its intended purpose, as outlined in this manual.
- If you experience any problems or accidents while using the product, report them to the appropriate authorities.

Specific Safety Precautions for Use

- Do not exceed the recommended weight limit of the strap to prevent breakage or accidents.
- Ensure that the strap is securely fastened around the gear before use.
- Avoid using the strap in extreme weather conditions that may affect its performance.
- Be cautious when adjusting the strap tension to prevent pinching or injury to your hands.
- Regularly check the Allen bolt for tightness and ensure it is properly secured.

Instructions for Installation and Usage

1. Attaching the GripON Long Strap:

- Loosen the strap by turning the Allen bolt counterclockwise.
- Place the strap around the gear you wish to attach (e.g., binoculars, tripod legs).
- Pull the strap snugly around the gear.
- Tighten the Allen bolt by turning it clockwise until it reaches the desired tension.

2. Adjusting the Strap Length:

- To adjust the length of the strap, loosen the Allen bolt and slide the strap to the desired length.
- Ensure that the strap is securely fastened before use.

3. Regular Maintenance:

- Inspect the strap regularly for any signs of wear or damage.
- Clean the strap with a damp cloth if necessary, and allow it to dry completely before storing.

Disposal Instructions

- Dispose of the GripON Long Strap in accordance with local regulations.
- Do not dispose of the strap in household waste. Instead, consider recycling options where available.

Contact Information for Further Support

For safety inquiries or additional support regarding the GripON Long Strap, please refer to the manufacturer's contact information provided with the product packaging.

Thank you for your attention to these safety instructions. We hope you enjoy using your GripON Long Strap safely and effectively!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk