Silicon case for SG Timer 2 - Timer 2 silicon case Camo

Excellent protection and grip. Designed specifically for SG Timer 2, the case doesn't reduce the magnetic strength when attaching to the Magnetic holder and fits over the buttons for ease of use.

Protects against scratches, drops and creates a protective bezel around the screen. The case ensures charging at full power with Magnetic charging holder and QI wireless chargers



Attributes

Name: Timer 2 silicon case CamoManufacturer: SHOOTERS GLOBAL

Product no.: EU2014532Mfr. No.: EU2014532

Color: Camo

Delivery weight: 1kg
Shipping height: 100mm
Shipping width: 100mm
Shipping length: 100mm
UPC: 634240337642

Table of Contents

- Startpage
 English: Safety Instruction Guide for Silicon Case for SG Timer 2

Safety Instruction Guide for Silicon Case for SG Timer 2

Introduction

Thank you for choosing the Silicon Case for SG Timer 2. This product is designed to provide excellent protection and grip while ensuring ease of use. This safety instruction guide is designed to help you use the product safely and effectively, in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always inspect the product for any visible damage before use.
- Ensure that the case is properly fitted to the SG Timer 2 to maintain its protective qualities.
- Keep the product away from extreme temperatures and moisture to avoid material degradation.
- Do not use the case if it shows signs of wear or damage.
- Store the product in a safe place, away from children and pets.

Specific Safety Precautions for Use

- Avoid exposing the case to sharp objects that could puncture or tear the silicone material.
- Do not attempt to modify or alter the case, as this may compromise its protective features.
- Ensure that the magnetic holder is securely attached to avoid accidental drops.
- When using with wireless chargers, ensure that the case is compatible to prevent overheating.
- Always follow the manufacturer's instructions for any devices used in conjunction with the case.

Instructions for Installation and Usage

1. Installing the Case:

- Gently slide the SG Timer 2 into the silicon case.
- Ensure that all buttons are accessible and that the case fits snugly without obstructing any functions.
- Check that the case does not interfere with the magnetic holder's attachment.

2. Using the Case:

- Use the buttons through the case as you normally would. The case is designed to allow easy access.
- When charging, ensure that the magnetic charging holder is properly aligned with the device.
- For wireless charging, place the device on the charger without removing the case, ensuring compatibility.

3. Removing the Case:

- Carefully peel the case away from the device, starting from one corner.
- Avoid using excessive force to prevent damage to the device or case.

Disposal Instructions

- Dispose of the silicon case in accordance with local waste management regulations.
- Do not dispose of the product in regular household waste.
- · Consider recycling options for silicone materials if available in your area.

Contact Information for Further Support

For any inquiries regarding safety or usage, please refer to the manufacturer's contact information included with your product packaging.

By following these guidelines, you can ensure safe and effective use of the Silicon Case for SG Timer 2. Thank you for your attention to these important safety instructions.