

Loading Gate Spring Cover Screw Marlin Smith & Wesson - Loading Gate Spring Cover Screw | Marlin, Smith & Wesson

[Zbrojářské nářadí](#) > [Drobné kovové prvky](#) > [Kovové šrouby](#)

The RPP Flyweight lever action Loading Gate greatly reduces the effort required to stoke your Rossi 95 It's a masterfully tuned, competition grade part right out of the gate. SASS approved.

Starting with a massive reduction in spring weight, the RPP gate requires only about 1.5 lbs. of force to open fully, while the factory loading gate can require in excess of 5 lbs.

Next, we redesigned the lever-action loading gate to offer substantially more clearance for cartridges, further reducing load effort. This is a significant benefit when loading fat, straight wall ammo like the Marlin 444. In fact, during testing we discovered that we could load a .444 dummy through the gate of a typical Marlin 336 .30-30, without benefit of the Model 444's magazine tube clearance bulge. That's first class leg room!

Finally, we paid very careful attention to the inside "feed lip" area of the gate, optimizing geometry to ease gate opening against an on-deck round, and offer smooth feeding, with perfect case head control. With every gate precisely CNC machined from solid bar stock and hand polished, consistent results are assured.

Material is 7075-T6 aluminum, the strongest grade available. Engineered for highly stressed air frames, 7075 has extraordinary fatigue strength for thousands of flex cycles without failure. When anodized, it has a surface hardness exceeding hardened steel, for excellent wear properties.

The Firearm Blog Review: Ranger Point Precision Cloverleaf Peep Sights + Flyweight Loading Gate Springs

RPP Flyweight Marlin Loading Gate Features:

- * Spring weight reduced by up to 70%
- * No tuning required, saving you time and hassle
- * Greatly increased cartridge clearance
- * No knife sharp edges
- * Easy loading and smooth, reliable feeding
- * Precisely machined from 7075-T6 aluminum billet and hard anodized for extreme durability
- * Available in black, gold, or clear anodized finish (silver color to closely match stainless rifles)
- * 10-15 minute installation time
- * Single Action Shooting Society (SASS) approved

NO IMAGE
AVAILABLE

INSTALLATION

A couple of good screwdrivers is all that's needed.

The gun will need to be partially disassembled - just go slow, and remember that each screw needs to return to its original home, so get a piece of cardboard box, draw an approximation of the receiver on it, and poke a hole in your drawing where each screw can rest until reassembly.

- 1) Clear the rifle & ensure the chamber and magazine are EMPTY.
- 2) Unscrew/remove the tang screw from the upper/rear receiver tang, and pull off the buttstock to the rear.
- 3) Partially open bolt/lever, remove lever pivot screw and slide lever out of the bottom of the receiver (no need to remove bolt)
- 4) De-cock the hammer with the safety disengaged. Push forward on the hammer spring bridge and pull or push out one side of its groove. This will free the hammer spring
- 5) Remove hammer pivot screw, bottom trigger plate screw and side support screws to free the trigger plate from the receiver.
- 6) Remove the trigger plate / lower tang from the bottom of the receiver (some gentle prying may be needed).
- 7) Pull the locking lug out of the bottom of the receiver and swing the carrier out of the receiver (no need to remove the carrier pivot screw)
- 8) Unscrew the loading gate spring (1" behind the loading gate opening) and install the new gate and screw it in

Reassemble in reverse order.

Atributy

- Název: [Loading Gate Spring Cover Screw | Marlin, Smith & Wesson](#)
- Výrobce: [RANGER POINT](#)
- Produkt č.: EU2014804
- Výrob. č.: 200
- Dodací hmotnost: 0.45kg
- Výška přepravy: 2.54mm
- Šířka přepravy: 6.35mm
- Délka přepravy: 6.35mm
- UPC: 850078134127

Obsah

- [Úvodní stránka](#)
- [Návod na bezpečné používání a instalaci pružiny krytu nabíjecího otvoru RPP Flyweight](#)
- [O nás](#)

Návod na bezpečné používání a instalaci pružiny krytu nabíjecího otvoru RPP Flyweight

Úvod

Děkujeme, že jste si zakoupili pružinu krytu nabíjecího otvoru RPP Flyweight. Tento výrobek byl navržen tak, aby zjednodušil a zefektivnil proces nabíjení vaší zbraně. Nicméně, jako u každého technického zařízení, je důležité řídit se bezpečnostními pokyny, abyste zajistili bezpečné a správné používání. Tento návod obsahuje důležité informace o bezpečnosti, instalaci a používání.

Obecné bezpečnostní pokyny

- Před použitím výrobku si důkladně přečtěte tento návod.
- Zajistěte, aby byla zbraň vždy vybitá a bezpečná před prováděním jakýchkoli úprav.
- Udržujte výrobek mimo dosah dětí a osob, které nejsou obeznámeny s používáním zbraní.
- Kontrolujte výrobek na poškození před každým použitím. Pokud zjistíte jakékoli poškození, výrobek nepoužívejte.
- V případě jakýchkoli pochybností se obraťte na odborníka nebo autorizovaný servis.

Specifická bezpečnostní opatření pro použití

- Používejte pouze s kompatibilními zbraněmi, jak je uvedeno v popisu produktu.
- Při instalaci a používání výrobku noste ochranné brýle a další vhodné ochranné pomůcky.
- Při manipulaci se zbraní dodržujte všechny bezpečnostní postupy a pokyny výrobce zbraně.
- Nikdy nezapomínejte na základní pravidla bezpečnosti se zbraněmi, jako je vždy mířit bezpečně a zajistit, aby byla zbraň v bezpečném stavu.

Pokyny pro instalaci a použití

1. Příprava na instalaci:

- Ujistěte se, že zbraň je vybitá a že komora a zásobník jsou prázdné.
- Připravte si potřebné nástroje, jako jsou šroubováky.

2. Kroky instalace:

- Odšroubujte šroub tang z horní části zadního úchyty a odstraňte pažbu.
- Částečně otevřete závěr/páku, odstraňte šroub pákového kloubu a vysuňte páku zespodu těla zbraně (není nutné odstraňovat závěr).
- Uvolněte kohoutek s deaktivovanou bezpečností. Stiskněte dopředu na mostě pružiny kohoutku a vytáhněte nebo zatlačte jednu stranu z drážky.
- Odstraňte šroub pákového kloubu, dolní šroub spouště a boční podpěrné šrouby, abyste uvolnili spoušťovou desku z těla zbraně.
- Odstraňte spoušťovou desku / dolní tang z těla zbraně (může být potřeba jemné vyklápění).
- Vytáhněte zajišťovací jazýček ze spodní části těla zbraně a otočte nosič ven (není nutné odstraňovat šroub pákového kloubu).
- Odšroubujte pružinu nabíjecího otvoru (1" za otvorem nabíjecího otvoru) a nainstalujte novou pružinu a zašroubujte ji zpět.
- Sestavte zbraň v opačném pořadí.

3. Použití:

- Po instalaci důkladně zkontrolujte, zda je vše správně namontováno.

- Při nabíjení zbraně dodržujte všechny bezpečnostní pokyny a ujistěte se, že zbraň je v bezpečném stavu.

Pokyny pro likvidaci

- Výrobek likvidujte v souladu s místními předpisy o odpadech.
- Zajistěte, aby byl výrobek zlikvidován způsobem, který neohrožuje životní prostředí.

Kontaktní informace pro další podporu

V případě dotazů nebo potřebujete další podporu, obraťte se na výrobce nebo autorizovaného prodejce.

O nás

Brownells Česká republika

Brownells Česko - Světově největší dodavatel součástí zbraní, zbrojního vybavení a příslušenství pro střelce.

www.brownells.cz