

Trigger Case RIGHT ORG

[Shooting Accessories](#) > [Duty Gear](#)

You've been carrying a spare trigger for years and the box is always too bulky for your rifle case or range bag. The OBi Trigger Case fixes that. This 3D-printed case is barely larger than your trigger, sliding into your gear with zero wasted space while keeping the spare part snug, protected, and easy to find.

Designed for shooters who actually use their kit, the OBi Trigger Case eliminates the annoying bulk of typical packaging so your spare trigger rides securely in your rifle case, range bag, or pack pocket — without rattling or getting lost. If you carry a spare trigger, this is a must-have.

NO IMAGE
AVAILABLE

Attributes

- Name: [Trigger Case RIGHT ORG](#)
- Manufacturer: [OBI SYSTEMS](#)
- Product no.: EU2015578
- Mfr. No.: OBi08001-ORG
- Colour: Orange
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 767637841351

Table of Contents

- [Startpage](#)
- [OBi Trigger Case Safety Instruction Guide](#)
- [About Us](#)

OBI Trigger Case Safety Instruction Guide

Introduction

Thank you for choosing the OBi Trigger Case. This guide provides essential safety instructions and guidelines to ensure the safe use of your product. Please read this guide carefully before using the OBi Trigger Case.

General Safety Guidelines

- Ensure that the OBi Trigger Case is used only for its intended purpose — storing and protecting spare triggers.
- Always inspect the case for any signs of damage or wear before use. Do not use if damaged.
- Keep the OBi Trigger Case out of reach of children and vulnerable individuals.
- Follow all local laws and regulations regarding the use and transport of firearm accessories.

Specific Safety Precautions for Use

- Do not overload the OBi Trigger Case with items other than spare triggers to maintain its protective qualities.
- Ensure that the case is securely closed when not in use to prevent accidental opening.
- Avoid exposing the OBi Trigger Case to extreme temperatures, moisture, or direct sunlight for prolonged periods.
- If you notice any unusual sounds or movements when using the case, stop using it immediately and inspect for any issues.

Instructions for Installation and Usage

1. Placing the Trigger in the Case

- Open the OBi Trigger Case by gently sliding the lid.
- Carefully place your spare trigger inside the case, ensuring it fits snugly.
- Close the lid securely until you hear a click, indicating that it is locked in place.

2. Storing the Case

- Store the OBi Trigger Case in a designated area of your rifle case, range bag, or pack pocket.
- Ensure that the case is positioned upright to prevent it from sliding around or becoming dislodged.

3. Transporting the Case

- When transporting, ensure that the OBi Trigger Case is stored in a secure location within your gear.
- Check that the case is not exposed to any sharp objects or heavy pressure that could cause damage.

4. Cleaning the Case

- To clean the OBi Trigger Case, use a soft, damp cloth to wipe the exterior.
- Avoid using harsh chemicals or abrasive materials that could damage the case.

Disposal Instructions

- When the OBi Trigger Case reaches the end of its useful life, dispose of it responsibly.
- Check local regulations for guidelines on disposing of plastic products.
- If possible, recycle the case according to local recycling programs.

Contact Information for Further Support

For safety inquiries or further assistance regarding the OBi Trigger Case, please refer to the contact information provided by your retailer or manufacturer.

Conclusion

By following these safety instructions, you can ensure the effective use of the OBi Trigger Case while maintaining safety standards. Thank you for being a responsible user, and enjoy your shooting experience!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk