

Trigger Case LEFT GY

[Shooting Accessories](#) > [Duty Gear](#)

You've been carrying a spare trigger for years and the box is always too bulky for your rifle case or range bag. The OBi Trigger Case fixes that. This 3D-printed case is barely larger than your trigger, sliding into your gear with zero wasted space while keeping the spare part snug, protected, and easy to find.

Designed for shooters who actually use their kit, the OBi Trigger Case eliminates the annoying bulk of typical packaging so your spare trigger rides securely in your rifle case, range bag, or pack pocket — without rattling or getting lost. If you carry a spare trigger, this is a must-have.

NO IMAGE
AVAILABLE

Attributes

- Name: [Trigger Case LEFT GY](#)
- Manufacturer: [OBI SYSTEMS](#)
- Product no.: EU2015581
- Mfr. No.: OBi08002-GY
- Colour: Gray
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 767637841382

Table of Contents

- Startpage
- OBi Trigger Case Safety Instructions
- About Us

OBi Trigger Case Safety Instructions

Introduction

Thank you for choosing the OBi Trigger Case. This innovative product is designed to securely store your spare trigger while minimizing bulk. To ensure safe and effective use of the OBi Trigger Case, please carefully read and follow the safety instructions provided in this guide.

General Safety Guidelines

- Ensure that the OBi Trigger Case is used solely for storing spare triggers.
- Regularly inspect the case for any signs of damage or wear. Do not use if damaged.
- Keep the case out of reach of children and vulnerable individuals to prevent accidental use.
- Always store your spare trigger in a safe and secure location.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Only use the OBi Trigger Case with compatible trigger models.
- Avoid exposing the case to extreme temperatures or harsh chemicals, as this may compromise its integrity.
- Do not overload the case with additional items; it is designed specifically for trigger storage.
- Ensure that the case is closed properly before storing it in your rifle case or range bag to prevent accidental opening.
- If you notice any unusual sounds or movements from the case while in storage, inspect it immediately.

Instructions for Installation and Usage

1. Installation:

- Open the OBi Trigger Case by gently pressing on the latch.
- Place your spare trigger inside the case, ensuring it fits snugly.
- Close the case securely until you hear a click, indicating it is locked.

2. Usage:

- When transporting, place the OBi Trigger Case in your rifle case, range bag, or pack pocket.
- Avoid placing heavy items on top of the case to prevent deformation or damage.
- Regularly check the case during transport to ensure it remains secure and intact.

Disposal Instructions

- When the OBi Trigger Case reaches the end of its life, dispose of it responsibly.
- Check local regulations for recycling or disposal options for plastic products.
- Do not incinerate the case, as this may release harmful substances.

Contact Information for Further Support

For any questions or concerns regarding the OBi Trigger Case, please contact the manufacturer or refer to the product packaging for further information.

Thank you for your attention to these safety instructions. Your safety is our priority, and we hope you enjoy using the OBi Trigger Case.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk