

ROPE HEARING ENHANCER W/ BLUETOOTH - WALKERS GAME EAR

ROPE HEARING ENHANCER WITH BLUETOOTH

[Shooting Accessories](#) > [Ear & Eye Protection](#) > [Ear Plugs](#)

The Walker's Rope Hearing Enhancer is a neck worn hearing enhancement that has a flexible rubber cord with Bluetooth capabilities. The Walker's Rope features sound activated compression with high and low modes, high gain omni directional microphones for clear sound enhancement, and HD speakers in the earbuds for wide range audio quality. Sound Activated Compression High / Low compression mode Powered by Rechargeable Li-Ion battery Continuous Working Hours: 15 hours High Gain Omni directional microphones for clear sound enhancement HD speakers in the earbuds for wide range audio quality 3 pairs of foam tips (S / M / L) included Rechargeable Lithium battery 12 inch USB charging cable included EVA Storage Case included NRR (Noise Reduction Rating) 29dB



Attributes

- Name: [WALKERS GAME EAR ROPE HEARING ENHANCER WITH BLUETOOTH](#)
- Manufacturer: [WALKERS GAME EAR](#)
- Product no.: 100044483
- Mfr. No.: GWP-RPHE-BT
- Colour: Flat Dark Earth
- NRR: 29 dB
- Style: Plugs
- Delivery weight: 0.113kg
- Shipping height: 51mm
- Shipping width: 114mm
- Shipping length: 191mm
- UPC: 888151025871

Table of Contents

- [Startpage](#)
- [ROPE HEARING ENHANCER W/ BLUETOOTH Safety Instruction Guide](#)
- [About Us](#)

ROPE HEARING ENHANCER W/ BLUETOOTH Safety Instruction Guide

Introduction

Thank you for choosing the Walker's Rope Hearing Enhancer with Bluetooth. This product is designed to enhance your hearing experience while providing comfort and convenience. Please read this safety instruction guide carefully to ensure safe usage and to maximize the benefits of your hearing enhancer.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the hearing enhancer out of reach of children and pets.
- Regularly inspect the device for any signs of damage or wear. Do not use if damaged.
- Use the product in accordance with the manufacturer's instructions.
- Be aware of your surroundings while using the hearing enhancer to avoid accidents.
- Do not expose the device to extreme temperatures, moisture, or direct sunlight.
- If you experience any discomfort or adverse effects while using the device, discontinue use immediately and consult a healthcare professional.

Specific Safety Precautions for Use

- **Hearing Safety:**
 - Be cautious of high volume levels. Prolonged exposure to loud sounds can cause hearing damage.
 - Adjust the volume to a comfortable level to avoid discomfort.
- **Battery Safety:**
 - Only use the provided rechargeable Lithium battery. Do not use other batteries.
 - Avoid shortcircuiting the battery terminals.
 - Do not attempt to disassemble the battery or device.
- **Bluetooth Connectivity:**
 - Ensure your Bluetooth device is compatible with the hearing enhancer.
 - Keep the hearing enhancer away from other electronic devices to avoid interference.

Instructions for Installation and Usage

1. Charging the Device:

- Connect the USB charging cable to the device and a power source.
- Allow the device to charge fully before first use (approximately 3 hours).
- The indicator light will turn off when fully charged.

2. Wearing the Device:

- Place the flexible rubber cord around your neck.
- Adjust the earbuds to fit comfortably in your ears. Try different sizes of foam tips (S, M, L) for the best fit.

3. Powering On/Off:

- To turn on, press and hold the power button until you hear a tone.
- To turn off, press and hold the power button again until you hear a tone.

4. Connecting via Bluetooth:

- Activate Bluetooth on your mobile device.
- Select "Walker's Rope Hearing Enhancer" from the list of available devices.
- Confirm the connection when prompted.

5. Using Sound Activated Compression:

- Switch between high and low compression modes as needed using the designated button.
- Monitor the sound levels and adjust as necessary for optimal hearing enhancement.

Disposal Instructions

- Dispose of the hearing enhancer and its components in accordance with local regulations.
- Do not dispose of the Lithium battery in regular waste. Check for local battery recycling programs.
- If the device is no longer functioning, consider returning it to the manufacturer for proper disposal.

Contact Information for Further Support

For any questions or concerns regarding the Walker's Rope Hearing Enhancer, please reach out to the manufacturer's customer support or visit their website for more information.

By following these guidelines, you can ensure a safe and enjoyable experience with your Walker's Rope Hearing Enhancer. Thank you for your attention to these important safety instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk