

NO. 2 1.5X MAGNIFICATION OPTICAL GLASS

[Gunsmith Tools](#) > [General Gunsmith Tools](#) > [Visors & Magnifiers](#)

Continuous Headband; Dial Adjustable

DIAL ADJUSTABLE CONTINUOUS HEADBAND - Specially formed to fit. A simple twist of the adjusting dial changes head size. Sealed-in mechanism is self-locking and trouble-free. Gives better balance and even more comfort. IT TILTS - Adjustable pivots make the OptiVISOR unique - and the most handy magnifier yet. It's up, out of the way of normal vision when not in use, and there at your fingertips when you need it for magnified pinpoint clarity back at the job. CONFORMING HEADBAND - Of electrically nonconductive ABS material. Designed to fit and locate the scope in a natural, comfortable position. Total weight just 4 oz. So light you hardly know it's there. GENUINE LEATHER COMFORT BAND - Padded with orthopedic felt, making the OptiVISOR the most comfortably worn magnifier available. ABS HI-IMPACT VISOR - This tough, durable material is practically indestructible, yet always keeps its new appearance. OPTICAL GLASS LENSES - Ground and polished to precision optical standards. Beveled edges and mounted in interchangeable plastic frames. Five scientifically computed prismatic powers are available for use with any OptiVISOR FITS OVER REGULAR GLASSES - No need to take them off with the OptiVISOR.



Attributes

- Name: [OPTIVISOR NO. 2 1.5X MAGNIFICATION OPTICAL GLASS](#)
- Manufacturer: [OPTIVISOR](#)
- Product no.: 255002000
- Mfr. No.: DA-2
- Delivery weight: 0.227kg
- Shipping height: 53mm
- Shipping width: 206mm
- Shipping length: 282mm
- UPC: 633096000472

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for OPTIVISOR No. 2 1.5X Magnification Optical Glass](#)
- [About Us](#)

Safety Instruction Guide for OPTIVISOR No. 2 1.5X Magnification Optical Glass

Introduction

Thank you for choosing the OPTIVISOR No. 2 1.5X Magnification Optical Glass. This guide provides essential safety information to ensure the safe use of your product. Please read this guide carefully before using the OPTIVISOR.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always inspect the OPTIVISOR before use for any visible damage or wear.
- Keep the product out of reach of children and vulnerable individuals.
- Do not use the OPTIVISOR if it is damaged or malfunctioning.
- If you experience discomfort or vision problems while using the OPTIVISOR, discontinue use immediately and consult a professional.

Specific Safety Precautions for Use

- **Headband Adjustment:** Use the dial adjustable headband to ensure a comfortable fit. Do not force the adjustment mechanism beyond its limits.
- **Tilt Mechanism:** Adjust the tilt of the visor carefully. Ensure it is securely locked in place before use.
- **Compatibility with Glasses:** The OPTIVISOR fits over regular glasses. Ensure your glasses are secure and properly positioned before wearing the OPTIVISOR.
- **Lens Care:** Avoid touching the optical glass lenses with your fingers. Clean lenses with a soft, lintfree cloth to avoid scratches.
- **Storage:** Store the OPTIVISOR in a safe, dry place when not in use. Avoid exposure to extreme temperatures or humidity.

Instructions for Installation and Usage

1. Adjusting the Headband:

- Place the OPTIVISOR on your head.
- Turn the adjusting dial to fit the headband comfortably around your head.
- Ensure the headband is snug but not too tight.

2. Using the Tilt Mechanism:

- Gently adjust the visor to the desired angle using the pivot points.
- Ensure the visor is tilted away from your normal line of sight when not in use.

3. Wearing Over Glasses:

- Position the OPTIVISOR over your regular glasses.
- Ensure that the glasses are not obstructed by the visor.

4. Cleaning the Lenses:

- Use a soft, lintfree cloth to clean the lenses.
- Avoid using abrasive materials or chemical cleaners.

5. Storing the OPTIVISOR:

- When not in use, place the OPTIVISOR in its protective case or a safe location.
- Keep it away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the OPTIVISOR in accordance with local regulations for electronic waste.
- Remove any batteries if applicable, and dispose of them separately in designated recycling containers.

Contact Information for Further Support

For any inquiries regarding the safety and usage of the OPTIVISOR, please refer to the manufacturer's contact details provided on the product packaging or manual.

Thank you for choosing the OPTIVISOR No. 2 1.5X Magnification Optical Glass. Your safety is our priority. Please follow these guidelines to ensure a safe and enjoyable experience with your product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk