

MEC POWDER BUSHINGS - MEC RELOADING #26 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [MEC RELOADING #26 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749010336
- Mfr. No.: 5026
- Size: #26
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 098489016780

Item details

Made in USA

Table of Contents

- Startpage
- MEC Powder Bushings #26 Safety Instruction Guide
- About Us

MEC Powder Bushings #26 Safety Instruction Guide

Introduction

Thank you for choosing the MEC Powder Bushings #26. This product is designed to help you adjust the powder load for your rounds safely and effectively. Please read this safety instruction guide carefully to ensure proper use and to minimize any risks associated with this product.

General Safety Guidelines

- Always use a scale to check powder weights for accuracy.
- Store powder bushings in a cool, dry place away from direct sunlight and moisture.
- Keep powder bushings out of reach of children and vulnerable individuals.
- Inspect the bushing for any damage or wear before each use.
- Do not exceed the recommended powder load specified for your bushing.
- Follow all manufacturer guidelines and recommendations for use.

Specific Safety Precautions for Use

- Ensure that the bushing is properly seated in the reloading press before use.
- Avoid touching the powder with bare hands to prevent contamination.
- Wear safety glasses to protect your eyes from any accidental spills or splashes.
- Use only compatible powders as specified in the MEC powder charts available on the MEC website.
- If you experience any issues or malfunctions while using the bushing, stop using it immediately and consult the manufacturer.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Remove any existing bushings from the press.
- Select the correct MEC Powder Bushing #26.
- Insert the bushing into the designated slot in the reloading press, ensuring it is securely seated.

2. Usage:

- Measure the required amount of powder using a scale.
- Carefully pour the powder into the bushing.
- Adjust the bushing to the desired setting according to the MEC powder charts.
- Reload your rounds following standard reloading procedures.

Disposal Instructions

- Dispose of any damaged or worn powder bushings in accordance with local regulations.
- Do not throw powder bushings in regular trash. Check with local waste management for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product issues, please refer to the MEC website or contact your

local MEC representative.

Conclusion

By following these safety instructions, you can ensure a safe and effective reloading experience with the MEC Powder Bushings #26. Always prioritize safety and refer to this guide as needed.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk