

MEC POWDER BUSHINGS - MEC RELOADING #9 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [MEC RELOADING #9 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019445
- Mfr. No.: 5009
- Size: -
- Delivery weight: 0.016kg
- Shipping height: 19mm
- Shipping width: 114mm
- Shipping length: 186mm
- UPC: 098489027939

Item details

Made in USA

Table of Contents

- Startpage
- MEC Powder Bushings Safety Instruction Guide
- About Us

MEC Powder Bushings Safety Instruction Guide

Introduction

Welcome to the MEC Powder Bushings Safety Instruction Guide. This document provides essential safety information and guidelines for the safe use of MEC Reloading #9 Powder Bushings. By following these instructions, you can ensure a safe and effective reloading experience.

General Safety Guidelines

- Always handle powder bushings with care to avoid spills and contamination.
- Store powder bushings in a cool, dry place away from direct sunlight and heat sources.
- Keep powder bushings out of reach of children and pets.
- Use a scale to check powder weights for accuracy to prevent overloading or underloading your rounds.
- Regularly inspect your powder bushings for wear or damage before each use.
- Familiarize yourself with the specific powder charts available on the MEC website to ensure proper usage.

Specific Safety Precautions for Use

- When adjusting the powder load, ensure the machine is turned off to prevent accidental discharge.
- Always wear safety glasses when reloading to protect your eyes from any potential hazards.
- Do not mix different types of powders in the same bushing.
- Ensure that the bushing you are using is compatible with the type of powder you are loading.
- If you experience any unusual behavior from your reloading equipment, stop using it immediately and consult the manufacturer.

Instructions for Installation and Usage

1. Installation of Powder Bushing:

- Ensure your reloading press is turned off and unplugged.
- Remove the existing bushing by unscrewing it from the press.
- Select the appropriate MEC powder bushing based on your desired load.
- Screw the new bushing securely into place, ensuring it is tightly fitted.

2. Usage of Powder Bushing:

- Turn on your reloading press and prepare your materials.
- Measure the powder using the installed bushing and check the weight with a scale.
- Adjust the bushing as necessary to achieve the correct powder load.
- After use, turn off the reloading press and clean any residual powder from the bushing.

Disposal Instructions

- Dispose of any damaged or worn powder bushings in accordance with local regulations.
- Do not throw powder bushings in regular household waste. Instead, check for local recycling programs or hazardous waste disposal sites.
- Ensure that all powder residues are cleaned from the bushings before disposal to prevent contamination.

Contact Information for Further Support

For any safety inquiries or concerns regarding the MEC Powder Bushings, please refer to the MEC website or contact your local MEC dealer for assistance.

By adhering to these safety guidelines and instructions, you can ensure a safe and effective reloading process with MEC Powder Bushings. Thank you for choosing MEC Reloading products.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk